



BAMP-604-N-A

**ALTAVOZ MULTIMEDIA – MICROSD – RADIO FM –
PANTALLA 1.8" – USB – GRABADORA**

Manual de Instrucciones

Gracias por comprar nuestro producto. Para garantizar un funcionamiento correcto lea cuidadosamente este manual antes de usarlo.

Medidas importantes de seguridad

- Mantenga los altavoces alejados del agua y otros líquidos.
- Mantenga los altavoces alejados de cualquier fuente de calor.
- Ajuste el volumen a un nivel adecuado a fin de evitar daños a sus oídos, o la propia unidad.
- Cargue la batería por completo antes de usar por primera vez.

Solución de problemas

1. ¿Qué debo hacer si la tarjeta Micro SD o USB Flash Disk no funcionan?

(1) Asegúrese de que la tarjeta Micro SD o USB Flash Disk está en buenas condiciones. Compruebe también que los archivos de audio son los formatos correctos - MP3 / WMA.

(2) Puede que exista algún problema de compatibilidad de la tarjeta Micro SD / disco flash USB. Le recomendamos formatear la tarjeta Micro SD o el USB stick a los formatos de archivos FAT32.

2. Estoy usando el modo de FM, pero no recibe ninguna estación de radio. ¿Cómo puedo mejorar la fuerza del que habla la señal de FM? Asegúrese que el altavoz está en un área capaz de recibir una señal de FM. Por favor, trate de usar un conjunto de auriculares o un cable de audio a modo de antena externa para mejorar la señal.

3. ¿Qué debo hacer si la función USB AUDIO no funciona?

(1) Conecte el altavoz al ordenador por medio del cable USB incluido, entrar en el modo USB AUDIO. A continuación, reproducir el vídeo/audio desde el ordenador.

(2) Si no puede usar esta función puede ser debido a problemas de incompatibilidad de la tarjeta de sonido del altavoz con el ordenador. Por favor, intente los siguientes pasos: haga clic derecho en Mi PC, haga clic en Propiedades en el menú contextual, haga clic en el hardware, haga clic en el administrador de dispositivos, haga clic en el signo "+", haga clic en el dispositivo de audio USB, haga clic en la desinstalación. Cambie el altavoz para el modo USB AUDIO de nuevo. El equipo se actualizará automáticamente para lograr la compatibilidad.

ESPECIFICACIONES

- Pantalla a color 1,8": Muestra el estado de trabajo, nombre de la canción, estaciones, etc.
- Conductor de altavoz doble: Doble bobina de voz interna que

permite un mejor sonido y Super Bass.

- Entrada USB-MicroSD: Soporta audio MP3-WMA-WAV
- Radio FM: con memorias. (FM Gama de frecuencias 87,5 MHz-108 MHz)
- Función de grabación
- Imagen y vídeo: AVI/AMV con resolución 128x160 e imágenes JPEG/BMP/GIF.
- Reloj, alarma, temporizador y apagado automático
- Conexión Usb para PC
- Batería de litio, bajo consumo, 1000 mAh (BL-5C).

CONTENIDO

Unidad

Cable USB

Cable de audio de 3.5mm

Batería (1000 mAh)

Manual de Usuario

Correa

Bolsa de transporte

FUNCIONAMIENTO

BOTÓN PLAY

Mantenga pulsado este botón para encender/apagar el altavoz

En modo Micro SD/USB: una pulsación corta para reproducir o pausar

En modo FM / AUX IN / USB AUDIO: Pulse brevemente para reproducir o silenciar.

BOTÓN AVANCE/RETROCESO

En modo Micro SD/USB: pulsación corta de la canción anterior/siguiente

En modo FM: Pulse brevemente para acceder a la estación anterior/siguiente de FM

BOTÓN M

Mantenga pulsado este botón para acceder al menú principal

Pulse AVANCE/RETROCESO para seleccionar el modo deseado y confirme la selección de nuevo con el botón M.

CONTROL DE VOLUMEN

Ajuste el volumen.

CONEXIONES

- Entrada auxiliar
- Conexión cable mini-USB para carga y PC
- Entrada USB
- Entrada de auriculares jack 3.5 mm,
- Entrada de tarjetas microSD

INICIO RÁPIDO

Encendido/Apagado: Mantenga pulsado el botón PLAY/PAUSA para encender el altavoz, se mostrará el menú principal. Mantenga pulsado de nuevo para apagar el altavoz.

Reproducción de MicroSD/USB: Coloque una tarjeta Micro SD o USB en el altavoz, pulse brevemente los botones para seleccionar el modo de música, a continuación, pulse el botón M para confirmar. El altavoz reproducirá el dispositivo insertado. Pulse brevemente avance/retroceso para pasar a la pista anterior o siguiente. Mantenga pulsado estos botones para avanzar rápidamente. Mantenga pulsado el botón M para salir de este modo.

Nota: En el modo música, la unidad reproducirá el último dispositivo insertado.

Radio FM: Pulse brevemente los botones para seleccionar el modo FM, pulse el botón M para confirmar. Pulse los botones para seleccionar el canal de radio anterior / siguiente (FM 87.5 a 108 MHz). Pulse brevemente el botón M para seleccionar ajustes secundarios como búsqueda automática, guardar estación, grabar radio, eliminar estación, etc. Mantenga pulsado el botón M para salir de este modo.

Nota: La unidad reproducirá la estación que se escucho por última vez. Puede mejorar la señal con un cable de auriculares o un cable de audio a modo de antena externa.

Grabadora: Insertar una tarjeta microSD o USB en la unidad. Pulse brevemente los botones para seleccionar el modo de grabación, pulse el botón M para confirmar. Pulse brevemente el botón PLAY para comenzar, parar y continuar con la grabación. Mantenga pulsado el botón PLAY para guardar los archivos grabados. Mantenga pulsado el botón M para salir de este modo.

Entrada auxiliar: Seleccione el modo de entrada auxiliar. Utilice el cable de audio de 3,5 mm incluido para conectar el altavoz a una fuente de audio (PC, MP3/MP4, teléfonos móviles).

USB: Use el cable USB para conectar el altavoz al ordenador, pulse brevemente el botón Mode para entrar en el modo de audio USB, que le permitirá usar el altavoz como altavoz de su ordenador. La primera vez que use esta función, el ordenador identificará automáticamente el altavoz e instalará el controlador para ello.

Reproducción de imágenes y vídeos:

Introduzca una tarjeta microSD o USB con imágenes o vídeos. Pulse los botones para seleccionar el modo imagen o vídeo, a continuación,

pulse el botón M para confirmar. Pulse el botón play para reproducir. Mantenga pulsado el botón M para salir de este modo.

Función tarjeta de memoria:

Ponga la tarjeta micro SD en el altavoz y utilice el cable USB para conectarlo al ordenador. El altavoz se encenderá automáticamente y cambiará modo lector de tarjetas. Entonces, el ordenador reconocerá automáticamente el dispositivo y podrá guardar información en la tarjeta Micro SD directamente.

Carga de batería:

Conecte el altavoz a su ordenador con el cable USB para la carga de la batería. También puede utilizar un adaptador 5V/1000mA (no incluido) Nota: No carga el altavoz más de 4 horas.

FUNCIONAMIENTO

Mantenga pulsado el botón M para salir del modo de trabajo actual. La pantalla LED mostrará el menú principal. Pulse cualquiera de los botones avance/retroceso para seleccionar el modo deseado: SYS Configuración, Calendario, entrada auxiliar, USB audio, música, vídeo, grabación, modo de FM o imagen. Pulse el botón M para confirmar.


1. Calendario

Entre en el modo calendario desde el menú principal. Para ver la fecha, hora, día de la semana y el año use los botones de avance y retroceso. La hora y fecha actual se pueden cambiar en el modo configuración del sistema.

2. Música

En este modo, el altavoz reproducir música desde la tarjeta MicroSD o USB. La pantalla LED muestra la información relacionada de la canción incluyendo el título de la canción, artista, álbum, tiempo de reproducción, la ecualización y el orden de reproducción.

(1) Cuando la música está en reproducción, presione el botón "M" para entrar en diferentes funciones como EQ, modo de repetición, etc. Pulse los botones avance/retroceso para seleccionar y el botón "M" para confirmar.

(2) Modo de repetición: Entre en la función de repetición e introduzca el modo de repetición (el icono  se mostrará en la parte inferior izquierda de la pantalla). Cuando la letra A comience a parpadear, pulse el botón play para ajustar el punto de inicio. Cuando la letra A deja de parpadear, el punto de inicio está establecido. Cuando la letra B comienza a parpadear, pulse el botón play para establecer el punto final. La función de repetición comenzará cuando las letras A&B dejen de parpadear.

(3) Eliminar archivos: Pulse el botón play para pausar la reproducción de la canción. A continuación, pulse el botón M para entrar en el menú de configuración de archivo y elija entre estas opciones: Eliminar archivos: Borrar todo, Atrás y Salir. Uso de los botones de avance/retroceso para elegir y el botón de M para confirmar.

3. Radio FM

La primera vez que utilice la función de radio FM, necesita sintonizar las emisoras. Entre en el modo FM, pulse el botón M para: "Búsqueda automática, Guardar, Grabación de FM, Eliminar, Eliminar todas Bandas, Salida." Pulse los botones avance/retroceso para seleccionar y el botón MENU para confirmar. Después de terminar la búsqueda automática de FM, los canales de radio se guardarán automáticamente.

4. Grabadora

Entre en el modo de grabación, pulse brevemente el botón play para iniciar la función de grabación, mantenga pulsado el botón play para guardar los archivos grabados. Pulse brevemente el botón M seleccionar otros ajustes: "Ubicación (MicroSD/USB), Tipo de REC y Salir". Desde el tipo de REC puede establecer 32K-64K-128K. A mayor tamaño de byte, mayor calidad de sonido pero los archivos grabados ocuparán más espacio en la memoria.

5. Fotos y vídeos

Entre en el modo de fotos. El dispositivo soporta los formatos JPEG/BMP/GIF y resolución 160x128. Pulse el botón play para ver las fotos, pulse avance/retroceso para pasar a la imagen anterior/siguiente y pulse el botón play otra vez para salir del modo de imagen. Después de salir de este modo, pulse el botón M para entrar en el ajuste secundario donde podrá seleccionar Micro SD/USB, eliminar archivos, eliminar todo y salir. Utilice los botones avance/retroceso para seleccionar y pulse el botón M para confirmar.

Entre en el modo vídeo. El dispositivo es compatible con AMV/AVI y resolución a 160x128. Pulse el botón play para reproducir vídeo. Pulse los botones avance/retroceso para seleccionar archivos anterior/siguiente y pulse el botón play otra vez para salir del modo. Después de salir de este modo, pulse el botón M para entrar en el ajuste secundario donde podrá seleccionar Micro SD/USB, eliminar archivos, eliminar todo y salir". Utilice los botones avance/retroceso para seleccionar y pulse el botón M para confirmar.

6. Settings

Entre en el modo configuración del sistema:

(1) Ajuste de la alarma

En la alarma, puede establecer las siguientes sub-opciones pulsando los botones avance/retroceso y M para confirmar: Alarma (on / off), tiempo, ciclo, señal de alarma, volumen, y salir. Y a continuación,

pulse el botón para volver al menú anterior.

(2) Ajuste de la hora

Entre en la función de introducir la hora, use los botones de avance/retroceso para ajustar el año/mes/fecha/hora. Pulse el botón M para confirmar. Y a continuación, pulse el botón para volver al menú anterior.

(3) Ajuste de la hora de apagado

Entre en el menú de ajustes, podrá elegir la hora de apagado de la unidad. En el sub-menú: Apague Set-Set Time FM-Salir. Mediante el uso de los botones de avance/retroceso podrá ajustar el tiempo de apagado automático. Pulse el botón M para guardar la configuración.

(4) Ajustes Radio FM

Podrá seleccionar "Apague Set-Set Time FM-Salir. A continuación, entrará en el ajuste secundario "Set Time FM, grabación de FM, Tiempo FM, banda FM y salida". Mediante el uso de los botones de avance/retroceso podrá ajustar el tiempo de apagado automático. Pulse el botón M para guardar la configuración.

"Las especificaciones pueden cambiar sin previo aviso"

Importado: I.R.P., S.L.
Avda. Santa Clara de Cuba 5
41007 Sevilla
Spain



DECLARACIÓN DE CONFORMIDAD

I.R.P., S.L. declara bajo su responsabilidad que el aparato indicado cumple los requisitos de las siguientes directivas:

DIRECTIVAS EMC

EN55013:2001+A1:2003+A2:2006
EN61000-3-2:2006+A1:2009+A2:2009
EN61000-3-3:2008
EN55020:2007

Descripción del aparato:

Modelo BRIGMTON **BAMP-604-A-N**
Radio con altavoz incorporado

Importador: I.R.P., S.L.
Dirección: Avda. Santa Clara de Cuba 5, 41007, Sevilla.



BAMP-604-N-A

**MULTIMEDIA SPEAKER – MICROSD - FM RADIO –
1,8" SCREEN – USB – VOICE RECORDER**

Manual de Instrucciones

Dear customer,
Thank you for purchasing our product. To ensure correct operation,
please read this user manual carefully before using it.

Important Safety Instructions

- ◆ Keep speaker away from water and other liquids.
- ◆ Keep speaker away from any source of heat.
- ◆ Adjust the volume to a suitable level so as to avoid damaging your hearing, or the unit itself.
- ◆ Charge the battery after totally using up for the first time working.

Troubleshooting

1. What should I do if the Micro SD card or USB Flash Disk do not work?

- (1) Ensure that the Micro SD card or USB Flash Disk is in good condition. Also check that the audio files are the correct formats - MP3 / WMA.
- (2) Beside the above case, the problem maybe the compatibility of the Micro SD card/USB flash disk. We recommend you formatting the Micro SD Card/USB flash disk to FAT32 file formats.

2. I'm using FM mode but the speaker cannot receive any radio channels. How can I improve the speaker's FM signal strength?
Make sure the speaker is in an area capable of receiving an FM signal. Please try using a set of earphone or an audio cable with the speaker. They act as an external antenna to enhance the signal. Or please try adjusting the speaker's direction for better FM signal reception.

3. What should I do if the USB AUDIO function could not work?

- (1) Connect the speaker to the computer via the USB cable included, and enter the USB AUDIO mode. And then play the video/ audio from the computer.
- (2) If it could not work, it may be the problem that the sound card of the speaker is incompatible with the computer. Please try below steps: right click My Computer---click Properties from the shortcut menu---click the hardware---click the device manager--- click the "+" in front of the Voice video and games controller---right click the USB Audio device---click the uninstall. Then please switch the speaker to USB AUDIO mode again. The computer will automatically update the USB sound card drive to achieve the compatibility


Features

- 1.8" Color screen display
Display the working status, song's name& lyric both in Chinese and English with easily operation
- Dual Voice Coil Driver
Peculiar Dual voice coil internal magnetic driver design, with better sound and super bass
- USB Flash Disk / Micro SD Card Music Playing
Dual decodes of MP3/WMA/WAV, support the entire MP3/WMA coding rate
- FM Radio
Support auto scan and save the FM channels, support FM Record (FM frequency Range 87.5 MHz—108MHz)
- Record Function
Record the sound and playing
- Browse Picture and Video playing
Support 128*160 Resolution JPEG/BMP/GIF format picture and AMV/AVI video
- Timer ,alarm and power off setting
Support Time/alarm. Power off setting
- Card Reader and One Cable Function
The 2.0 card reader, USB sound card and charging functions can be achieved via the same USB cable
- Removable Li battery
Low power consumption design with the 1000 mAh BL-5C battery.

Package Contents

Speaker, USB Cable, 3.5mm Audio Cable, Lithium-Ion battery(1000 mAh), User Manual, Strap, speaker pouch.


Keys

(1) 

Long press this button to power on/ off the speaker


Micro SD Card/ USB Flash Disk Mode: short press to play/Pause

FM/AUX IN/USB AUDIO: Short press to play/mute.

(2) 

Micro SD Card/ USB Flash Disk Mode: short press for the previous song

FM Mode: Short press for previous FM channel



(3) 

Micro SD Card/ USB Flash Disk Mode: short press for the next song

FM Mode: Short press for next FM channel

(4) **M**

Long press this button to enter the main menu

Press  or  to select the mode of Micro SD Card, USB Flash Disk, FM Radio, Record etc., when select the mode, Short press 'M' button to confirm and enter into the mode.

(5) Volume roller



Adjust the volume via the roller

Jack and Slot




- (1) Aux In jack
- (2) Charging and the USB Cable jack
- (3) USB Flash Disk Slot
- (4) Earphone Jack
- (5) Micro SD Card Slot

Quick Start

(1) Power on/off




Long press the "" button to power on the speaker, it will show the main menu. Long press the "" button again to power off the speaker.

(2) Micro SD Card/ USB Flash Drive Music Play

Place a Micro SD Card/USB Flash Disk into the speaker, short press the  buttons to select the music mode, then press the **M** button to confirm. The speaker will play the Micro SD card/USB Flash Disk music accordingly. Short press the  /  buttons for previous/next song, long press the  /  buttons for fast – forward or fast-reverse. Press the  button for play/pause. Long press the **M** button to exit this mode.

Please Note: Under Music mode, the last inserted device will be played first. For example: The speaker is playing music from USB flash disk, then inserting the Micro SD card, the speaker will begin to play music form Micro SD card.





(3) FM Radio

Short press the  buttons to select the FM mode, then press the **M** button to confirm. Press the  /  buttons to select the previous/ next radio channel (FM frequency from 87.5 to 108 MHZ). Short press the **M** button to select the sub setting: "Auto Search, FM Save, FM Record, Delete Channel etc." Long press the **M** button to exit this mode.

Please Note: The speaker can remember the FM channel of last

time played before power off. When inserting the earphone or 3.5mm audio cable into the speaker, which can act as the external antenna to enhance the FM signal.

(4) Recorder

Please put the Micro SD Card/ USB disk into the speaker. Short press the /  buttons to select the Record mode, then press the **M** button to confirm. Short press the  button to "begin, pause and continue the record". Long press the  button to save the recorded files. Long press the **M** button to exit this mode.




(5) Aux In

Enter the Aux In mode. Use the 3.5mm audio cable included to connect the speaker to an audio source (PC, MP3/MP4, mobile phone). The speaker will play the music from the audio source.


(6) USB AUDIO

Please use the USB cable to connect the speaker to the computer, short press the Mode button to enter the USB Audio Mode, which will work as a computer speaker. The first time to use this function, computer will automatically identify the speaker and install the driver for it.

(7) Browse Picture and Video playing

Please put the Micro SD Card/ USB disk into the speaker (Saved with the picture/ video). Press the /  buttons to select Picture/video mode, then press the **M** button to confirm. Press the  button to browse the picture/play video. Long press the **M** button to exit this mode.

(8) Card Reader Function



Put Micro SD card into the powered off speaker and use the USB cable to connect it to the computer. The speaker will automatically power on and switch to card reader mode, and display  on the LED. The computer will then automatically recognize the device and the Micro SD card will be able to be read /written on the computer directly. Please note the card reader function is for Micro SD Card Only.

(9)Charging Function



Please connect the speaker to the computer by the included USB cable for charging. It also can use the branded 5V/1000mA adaptor for charging.

Please Note: Not charging the speaker more than 4 hours

Instructions










Long press the **M** button to exit the current working mode. The LED screen will display the main menu. Press either  /  buttons to select the mode you require: SYS Settings, Calendar, Aux In, USB AUDIO, Music, Video, Record, FM Mode or Picture. Press the **M** button again to confirm.

1. Calendar



Enter the calendar mode, to view the date, time, day of the week, and year by using the   buttons. The current time and date can be set in the system time under system setting.

2. Music



Under this mode, the speaker will play music from Micro SD Card/ USB Flash Disk. The LED screen will display the related information of the song including the song's title, artist, album, playing time, code rate, EQ and the playing order.

- (1) When music is under playing, press the "**M**" button to enter "Cycle Mode, EQ Setting, Repeat Mode, and Exit". Press the   buttons to choose and the "**M**" button to confirm.
- (2) Repeat Mode: From MENU, enter the repeat function for "Repeat Mode, Repeat Times and Repeat Interval".
Enter Repeat Mode (the  icon will be displayed at the left bottom of the LED screen). When the letter A begins to flash, press the  button to set the start point. When the letter A stops flashing, the start point is set. When the letter B begins to flash, press the  button to set the end point. The repeat function will commence when the letters A&B stop flashing.
Enter Repeat Times can set the times of the repeated content.
Enter Repeat Interval can set the repeat content's intervals.
- (3) Delete File: Press the   button to pause playing the song. Then press **M** button to enter the file setting menu: "Micro SD Card Files, USB Flash Disk Files, Delete Files, Delete All, Back and Exit". Using the   buttons to choose and the **M** button to confirm.



3. FM



The first time to use the FM function, need to auto search the local FM channels. Enter the FM mode, press the **M** button for: "Auto Search, Save Channel, FM record, Delete Channel, Delete All, Common Band, Japan band, Exit." Please press the   buttons to choose and the MENU button to confirm. After finishing the FM auto search, the radio channels will be saved on the speaker.

4. Recorder

Enter the Recorder mode, short press the  button to start the record function, long press the  button to save the recorded files. Short Press the **M** button for the sub setting "Record Gain Set(Micro SD/USB), REC Type and Exit". From the REC Type can set the record byte (32K-64K-128K).The byte larger, the sound quality will be higher, meanwhile the recorded files will take up more memory space.

5. Browse Picture and Video playing


Enter the picture mode, the speaker supports to browse picture (format: JPEG/BMP/GIF), and the resolution at 160*128. Press the  button to browse the pictures, press the |</>| buttons for previous/next picture, and press the  button again to exit the picture mode. After exiting this mode, press the M button to enter the sub setting " Micro SD/USB Files, Playing Setting, Delete Files, Delete All, Exit ". Use the |</>| buttons to choose, and press the M button to confirm.

Enter the Video mode, the speaker supports to play the video format AMV/AVI, and the resolution at 160*128. Press the  button to play video, press the |</>| buttons for previous/next video, and press the  button again to exit the picture mode. After exiting this mode, press the M button to enter the sub setting " Micro SD /USB Files, Playing Setting, Delete Files, Delete All, Exit ". Use the |</>| buttons to choose, and press the M button to confirm.


6. System Setting

Enter the system setting, it will display: "Alarm, System Time, Backlight, Tool, Firmware Version, Reset Setting, Exit". Press the button to return to the previous menu.

(1) Alarm Setting

In Alarm, you can set the following sub-settings by pressing the |</>| buttons and **M** button to confirm: Alarm (on/off), Time, Cycle, Alarm Signal, Volume, and Exit. And then press the  button to return to the previous menu.

(2) System Time Setting

Enter System Time and use the |</>| buttons to adjust the year/month/date/time. Press **M** button to confirm. And then press the  button to return to the previous menu.

(3) Power Off Time Setting

Enter the Tool setting. In Tool, you can choose the power off set from the sub menu "Power off Set, Time FM Set, and Exit". By using the |</>| buttons to adjust the power off time (with the unit of minute), and press the M button to save the setting.

(4) Time FM Set

Enter the Tool setting. In Tool, you can choose the Time FM set from the sub menu "Power off Set, Time FM Set, and Exit". Then will enter the sub setting "Time FM Set, FM Record, FM Time, FM band and Exit". By using the |</>| buttons enter, and press the M button to save the setting.

"Features can change without notice"

Imported: I.R.P., S.L.
Avda. Santa Clara de Cuba 5
41007 Sevilla
Spain

DECLARATION OF CONFORMITY

I.R.P., SL declare under our responsibility that the equipment meets the requirements indicated in the following directives:

EMC DIRECTIVES

EN55013: 2001 + A1: 2003 + A2: 2006
EN61000-3-2: 2006 + A1: 2009 + A2: 2009
EN61000-3-3: 2008
EN55020: 2007

Description of apparatus:

BRIGMTON Model **BAMP-604-A-N**
Radio with built-in speaker

Importer: I.R.P., SL
Address: Avenida Santa Clara de Cuba 5, 41007, Sevilla.

